




# Installing The Cpu - Asus Z170-K User Manual



1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85



•

[Table of Contents](#)

•

## Bookmarks







Unplug all power cables before installing the CPU.

·  
·  
·

### 1.3.1



## Installing the CPU



1-4

Ensure that you install the correct CPU designed for the LGA1151 socket only. DO NOT install a CPU designed for LGA1150, LGA1155 and LGA1156 sockets on the LGA1151 socket.

Upon purchase of the motherboard, ensure that the PnP cap is on the socket and

the socket contacts are not bent. Contact your retailer immediately if the PnP cap is missing, or if you see any damage to the PnP cap/socket contacts/motherboard components.

Keep the cap after installing the motherboard. ASUS will process Return Merchandise Authorization (RMA) requests only if the motherboard comes with the cap on the LGA1151 socket.

The product warranty does not cover damage to the socket contacts resulting from incorrect CPU installation/removal, or misplacement/loss/incorrect removal of the PnP cap.



## Chapter 1: Product introduction

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
11  
12  
13  
14  
15  
16  
17  
18

Quick Links:

[Motherboard Overview](#)

[Motherboard Layout](#)

[System Memory](#)

[Connectors](#)

[Onboard Led](#)

## Related Manuals for Asus Z170-K

[Motherboard Asus B150-A Technical Manual](#)

Pin definition (18 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Accessory Installation Manual](#)

(10 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus SABERTOOTH Z170 Manual](#)

(174 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

## Related Content for Asus Z170-K

[H310M-IM-A Installing The Cpu](#)

Asus H310M-IM-A

[P11C-E/4L Installing The Cpu](#)

Asus P11C-E/4L

[A7V600-F/S Installing The Cpu](#)

Asus A7V600-F/S

[H610M-IM-A Installing The Cpu](#)

Asus H610M-IM-A

[P11C-I Installing The Cpu](#)

Asus P11C-I

[P11C-X Installing The Cpu](#)

Asus P11C-X

[P11C-X/AUDIO Installing The Cpu](#)

Asus P11C-X/AUDIO

[KRPA-U16 Installing The Cpu](#)

Asus KRPA-U16



This manual is also suitable for:

Z170-p

[Save PDF](#)