



Asus Cliques R100 User Manual

Wireless music streamer

1	
Table Of Contents	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	

--

•

•

Bookmarks

--

Quick Links

[1 Connecting to Wi-Fi Home Network](#)

[2 Connecting Speakers/ Audio System](#)

[3 Playing Music on Your Mobile Device](#)

[4 Connecting to Spotify](#)

[5 Firmware Upgrade](#)

[Download this manual](#)



Wireless Music ASUS Streamer

WARNING! This product may contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. Wash hands after handling.

Clique R100

Clique R100



User Guide

FCC ID: PPD-CUS227

XXX-

CCAI13LP1670T4

XXXXXXX

E10724 / First Edition / August 2015

IC: 4104A-CUS227

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus Clique R100

[Media Player Asus Clique R100 Quick Start Manual](#)

Wireless music streamer (2 pages)

[Media Player Asus Clique R100 Quick Start Manual](#)

Wireless music streamer (2 pages)

[Media Converter Asus Xonar Essence One Quick Start Manual](#)

Hi-fi usb digital-to-analog (92 pages)

[Media Converter Asus XONAR ESSENCE ONE User Manual](#)

Hi-fi usb dac (22 pages)

[Media Converter ASUS Essence 3 User Manual](#)

Hi-fi usb dac (digital-to-analog converter) (18 pages)

[Media Converter Asus Xonar Essence One Switching Manual](#)

Hi-fi usb dac opamp swap guide (5 pages)

[Media Converter Asus Essence One Series User Manual](#)

Hi-fi usb dac (digital-to-analog converter) (32 pages)

[Media Converter Asus Essence One Manual](#)

Hi-fi usb dac (digital-to-analog converter) dsd upgrade kit (7 pages)

[Media Converter Asus WMP-N12 Quick Start Manual](#)

Wireless-n300 audio streamer (10 pages)

[Media Converter Asus Xonar Essence STU Quick Start Manual](#)

(2 pages)

[Media Converter Asus Xonar Essence STU Quick Start Manuals](#)

Hi-fi usb dac (digital-to-analog converter) (2 pages)

[Media Converter Asus Xonar Essence STU Quick Start Manual](#)

Hi-fi usb dac (digital-to-analog converter) (2 pages)

[Media Converter Asus Xonar Essence One Quick Start Manual](#)

Hi-fi usb dac(digital-to-analog converter) (2 pages)

Summary of Contents for Asus Clique R100

[Page 1: User Guide](#)

Clique R100 Wireless Music Streamer User Guide FCC ID: PPD-CUS227 IC: 4104A-CUS227 XXX-CCAI13LP1670T4 XXXXXXXX WARNING! This product may contain chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. Wash hands after handling.

[Page 2: Table Of Contents](#)

Playing music on your mobile device8 Streaming music from your home network11
Playing music from music services12 Connecting to Spotify13 Multi-zones
.....14 Multi-room (Party mode)14 Settings15 Firmware upgrade
.....16 Clique R100 User Guide...

[Page 3: Safety Information](#)

12. Do not attempt to repair or disassemble this product. Consult ASUS Service Center (<http://www.asus.com/support/>) for support. Product features •...

[Page 4: Specifications](#)

Weight: 65 g • NOTE: * Ensure that your mobile device supports the audio format to successfully stream audio files. Package contents This package should contain the following: • ASUS Cliques R100 Wireless Music Streamer x1 • S/PDIF adapter x1 • Power adapter x1 • Multi-language QSG x1 System requirements • Mobile device (on iOS 6.0 and Android 2.3.3 or later) with AllPlay Jukebox • 802.11a/b/g/n Access Point (802.11n is recommended for best streaming quality) • WPA2 and mixed mode; WPA2/WPA compliant • Speakers or audio system with AUX or S/PDIF interface Cliques R100 User Guide...

[Page 5: I/O Description](#)

Rapidly flashing blue/green: Power on • Rapidly flashing blue: Entering reset mode • Slowly flashing green: Not connected to the home network; reset • mode* • Solid green: Connected to the home network Solid blue: Reset mode • LED off: Standby mode • NOTE: * You can see R100 labeled as Allplay_xxxxxx_AJ on your list of available Wi-Fi networks. Cliques R100 User Guide...

[Page 6: Connecting Speakers/ Audio System](#)

To connect to Wi-Fi home network: Connect your R100 to your audio system and plug to a power source. Wait until the LED turns into slowly flashing green to indicate that it is on setup mode. On your mobile device, connect to your R100 labeled as Allplay_xxxxxx_AJ (xxxxxx:MAC) on your list of available Wi-Fi networks. Cliques R100 User Guide...

[Page 7](#) On some mobile devices, the web browser launches automatically. Assign a unique name for your R100 to identify it in the AllPlay Jukebox app. Connect your R100 to your network. The LED turns to solid green to indicate a successful connection. Ensure that your mobile device is connected to the same network as your R100. Cliques R100 User Guide...

[Page 8: Playing Music On Your Mobile Device](#)

Launch AllPlay Jukebox on your mobile device and wait for your R100 to display. NOTES: • A list of all available Cliques R100 or AllPlay-compatible devices is displayed. • Depending on the network speed, it may take about one minute for the list of available devices to display. Tap the device that you want to play music to. Cliques R100 User Guide...

[Page 9](#) Tap Music on xxx (xxx stands for your mobile device's name). All the songs on your mobile device are displayed. Browse the list and add the songs you want to play to your playlist. Cliques R100 User Guide...

[Page 10](#) Tap to turn on/off the volume adjustment bar Tap to play the next song Tap to play or pause the song Tap to play the previous song Tap to toggle between the playlist and the currently-playing song Cliques R100 User Guide...

[Page 11: Streaming Music From Your Home Network](#)

Streaming music from your home network With Cliques R100, you can stream music from devices on your network such as NAS devices, computers, or music servers. To stream music from your home network: Ensure that your computer or other devices are connected to the same Wi-Fi network as Cliques R100. Tap Music on the Network, then select the device you want to access your songs from.

[Page 12: Playing Music From Music Services](#)

Supported music services: • AllPlay Radio (powered by TuneIn) • Astro Player (music player) • Aupeo • Dar.fm • Doubletivist (music player) • Napster • Rhapsody (only in the US) • Soma FM • Spotify (only in Europe and the US) Cliques R100 User Guide...

[Page 13: Connecting To Spotify](#)

On your tablet, tap . Select your Cliques R100 from the device list. If you cannot see it, ensure that your Cliques R100 and mobile device are connected to the same Wi-Fi network. NOTE: Spotify is subject to third party licenses found here: www.spotify.com/connect/third-party-licenses...

[Page 14: Multi-Zones](#)

Wi-Fi network. Multi-room (Party mode) Multi-room/ Party mode needs two or more Cliques R100 connected to the same network. It supports up to 10 Cliques R100 in 300Mbps network. We

recommend that you use two (2) to four (4) Clique R100 for better performance.

[Page 15: Settings](#)

Settings The settings screen provides access to various system settings. Tap to rename your Clique R100 device, restart AllPlay Jukebox, or the player Displays the signal strength received by Clique R100...

[Page 16: Firmware Upgrade](#)

Firmware upgrade To upgrade the firmware: From your computer, go the Clique R100 product page to download the latest firmware version. Ensure that your computer is connected to the same network as your Clique R100. Launch AllPlay Jukebox's Settings page to find the IP address of Clique R100. From your computer, launch a web browser and enter the IP address of Clique R100.

[Page 17](#) Click Choose file and locate the latest firmware file that you downloaded earlier. Click Flash Image and it takes about one (1) minute to upload the firmware file to your Clique R100. Clique R100 User Guide...

[Page 18](#) Click Proceed to install the firmware. When firmware upgrade is completed, Clique R100 restarts automatically. 10. Launch a web browser and enter the IP address of Clique R100 to check that the latest firmware version has been upgraded successfully. Clique R100 User Guide...