Connecting A Printer - Toshiba P100-ST7211 User Manual

P100-st7211 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
Table Of Contents
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267

268
269
270
271
272
273
274
275

Table of Contents

-

Bookmarks



Connecting a printer

NOTE

You can connect a USB-compatible printer to your computer
through the USB ports. To determine if the printer is USB-compatible, check its documentation.

To make the connection, you need a suitable USB cable,

which may come with your printer. If a USB cable was not included with your printer, you can purchase one from a computer or electronics store.

If your printer supports Plug and Play, your computer will automatically recognize the printer; the printer is then ready

for use. Refer to your printer documentation for further instructions.

If your printer does not support Plug and Play, you must set up the printer as described in the

page

70.

To connect a USB printer to your computer:

1

Connect the printer cable to the printer and then connect the other end to one of the computer's USB ports.

2

Plug the printer's power cable into a live electrical outlet.

Your printer documentation may require you to install the printer software before physically connecting the printer to your computer. If you do not install the software as instructed by the printer manufacturer, the printer may not function correctly.

Read the documentation that came with your printer. Follow the manufacturer' s instructions when connecting a local printer.

TECHNICAL NOTE: To determine if your printer supports Plug and Play, check its documentation.

ManualsLib.com

Getting Started

Connecting a printer

"Setting up your printer" on

69

Table of Contents

Previous Page
Next Page

Related Manuals for Toshiba P100-ST7211

Laptop Toshiba Satellite P100 Series User Manual

(196 pages)

Laptop Toshiba Satellite P100-ST7211 Series Specifications

Toshiba satellite p100-st7211: specifications (8 pages)

Laptop Toshiba Satellite P100 Series Maintenance Manual

Pc (314 pages)

Laptop Toshiba Satellite P100 Series Maintenance Manual

(311 pages)

Laptop Toshiba P100/P105 User Manual

Toshiba satellite p100/p105 series user's guide (280 pages)

Laptop Toshiba P105-S9337 User Manual

P105-s9337 user's guide (278 pages)

Laptop Toshiba P100-ST1072 User Manual

P100-st1072 user's guide (237 pages)

Laptop Toshiba PSPA3C-SD402E User Manual

User manual (172 pages)

Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual

Pa3943u-1cam camileo p100 user's guide (146 pages)

Laptop Toshiba Satellite P100/P105Series Resource Manual

Toshiba laptop pc user's guide (72 pages)

Laptop Toshiba Satellite P105-S6014 Specifications

Toshiba satellite p105-s6014: specifications (11 pages)

Laptop Toshiba Satellite P105-S6024 Specifications

Toshiba satellite p105-s6024: specifications (11 pages)

Laptop Toshiba Satellite P105-S6084 Specifications

Toshiba satellite p105-s6084: specifications (11 pages)

Laptop Toshiba Satellite P105-S6104 Specifications

Toshiba satellite p105-s6104: specifications (11 pages)

Laptop Toshiba Satellite P105-S6134 Specifications

Toshiba satellite p105-s6134: specifications (11 pages)

Laptop Toshiba Satellite P100 Specifications

Toshiba satellite p100: specifications (2 pages)

Related Content for Toshiba P100-ST7211

Portégé 650CT Connecting A Parallel Printer

Toshiba Portégé 650CT

Satellite T210 Series Connecting A Printer

Toshiba Satellite T210 Series

Satellite P200 Series Connecting A Printer

Toshiba Satellite P200 Series

Qosmio X300 Series Connecting A Printer

Toshiba Qosmio X300 Series

Tecra A9 Series Connecting A Printer

Toshiba Tecra A9 Series

Satellite 200 Series Connecting A Parallel Printer

Toshiba Satellite 200 Series

Portégé R830 Series Connecting A Printer

Toshiba Portégé R830 Series

SatellitePro L700 Series Connecting A Printer

Toshiba SatellitePro L700 Series

This manual is also suitable for:

P100-st7111P100-st9012P100-st9212P100-st9412P100-st9612P105-s6002 ... Show all