Using And Configuring Sleep Mode - Toshiba S300-EZ1511 User Manual

S300-ez1511 user's guide

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
Table Of Contents
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251

•

Table of Contents

-

Bookmarks



❖

❖

6

Click Apply.

7

Click OK.

Once the computer is configured, you can place it into Hibernation
mode by either pressing the power button or closing the display panel, depending on the Hibernation options set.

Starting again from Hibernation mode

To start up the computer from Hibernation mode, press the power button until the ON/OFF light glows green. The computer returns to the screen(s) you were using.

If you put the computer in Hibernation mode by closing the display
panel, you can start it again by opening the display panel.

Using and configuring Sleep mode

To turn off the computer using the Sleep command:

1

Click Start, and then click the arrow next to the Lock button in the lower-right part of the Start menu.

The Shut Down menu appears.

Start

(Sample Image) Shut Down menu

Power button action

ManualsLib.com

Set this option to Hibernate if you want the computer to go into Hibernation mode when you press the power button.

Start menu power button

Set this option to Hibernate if you want the computer to go into Hibernation mode when you click the power button in the Start menu.

Arrow

Shut Down Menu

Table of Contents

Previous Page
Next Page

Quick Links:

If Problems Arise
Adding Memory (Optional)
Power and the Batteries

Related Manuals for Toshiba S300-EZ1511

Laptop Toshiba S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz User Manual

Toshiba user's guide for satellite s300/s300m (windows vista) (242 pages)

Laptop Toshiba TECRA A10/S10/M10/SATELLITEPRO S300 TECRA S10 User Manual

Vizio mouse user manual (240 pages)

Laptop Toshiba SATELLITEPRO S300 User Manual

Toshiba laptop user manual (56 pages)
Laptop Toshiba Satellite Pro S300 Maintenance Manual
(464 pages)
Laptop Toshiba PTMB3U-00X00X User Manual
User manual (242 pages)
Laptop Toshiba TECRA A10 Satellite Pro S300 Series User Manual
(242 pages)
Laptop Toshiba Satellite Pro S300L-SP5919C Manual Del Usuario
User's guide for satellite pro s300l (spanish) (español) (240 pages)
Laptop Toshiba Satellite Pro S300L Series User Manual
(209 pages)
Laptop Toshiba Satellite Pro S300-EZ1512 Specifications
Toshiba satellite pro s300-ez1512: specifications (5 pages)
Laptop Toshiba Satellite Pro S300-EZ1513 Specifications
Toshiba satellite pro s300-ez1513: specifications (5 pages)
Laptop Toshiba Satellite Pro S300-EZ1514 Specifications
Toshiba satellite pro s300-ez1514: specifications (5 pages)
Laptop Toshiba Satellite Pro S300-EZ2501 Specifications
Toshiba satellite pro s300-ez2501: specifications (5 pages)
Laptop Toshiba Satellite Pro S300-S2503 Specifications
Toshiba satellite pro s300-s2503: specifications (5 pages)
Laptop Toshiba Satellite Pro S300-S2504 Specifications
Toshiba satellite pro s300-s2504: specifications (5 pages)
Laptop Toshiba Satellite Pro S300M-EZ2402 Specifications
Toshiba satellite pro s300m-ez2402: specifications (5 pages)
Laptop Toshiba Satellite Pro S300M-S2403 Specifications
Toshiba satellite pro s300m-s2403: specifications (5 pages)

Related Content for Toshiba S300-EZ1511

X305-Q705 - Qosmio - Core 2 Duo GHz Using And Configuring Sleep Mode
Toshiba X305-Q705 - Qosmio - Core 2 Duo GHz
P505 S8970 - Satellite - Core 2 Duo 2.2 GHz Using And Configuring Sleep Mode
Toshiba P505 S8970 - Satellite - Core 2 Duo 2.2 GHz
S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz Using And Configuring Sleep Mode
Toshiba S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz
R10 S4401 - Tecra - Core 2 Duo 2.26 GHz Using And Configuring Sleep Mode
Toshiba R10 S4401 - Tecra - Core 2 Duo 2.26 GHz
L45-S7423 - Satellite - Pentium Dual Core 1.46 GHz Using And Configuring Sleep Mode
Toshiba L45-S7423 - Satellite - Pentium Dual Core 1.46 GHz
M400 - Portege - Core 2 Duo 1.83 GHz Using And Configuring Sleep

Mode

Toshiba M400 - Portege - Core 2 Duo 1.83 GHz

Qosmio X305-Q701 Using And Configuring Sleep Mode

Toshiba Qosmio X305-Q701

Portege M750-S7221 Using And Configuring Sleep Mode

Toshiba Portege M750-S7221

This manual is also suitable for:

S300-ez1512S300-ez1513S300-ez2511S300-ez1514S300-s2503S300-ez2502 ... Show all