



# Toshiba FPT-AG01 Owner's Manual

Owners manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

•

[Table of Contents](#)

- 

Troubleshooting

•

## Bookmarks

## Quick Links

[1 Table of Contents](#)

[2 Specifications](#)

[Download this manual](#)





TOSHIBA

**TOSHIBA**

Leading Innovation

**Leading Innovation >>>**

>>>

Owner's Manual

**Owner's Manual**

3D Glasses

(FPT-AG01U)

**3D Glasses**

Contents

**(FPT-AG01U)**

[Safety Precautions](#)

2

[Accessories](#)

6

[Each part's name and function](#)

6

[Precautions for daily use](#)

7

[Enjoying 3D images](#)

8

[Replacing the battery](#)

9

[Care and Storage](#)

9

[Troubleshooting](#)

10

[Specifications](#)

11

Thank you for purchasing a Toshiba product.

- Please read this manual carefully and use this product safely and correctly.

Before use, be sure to read

it  
Safety Precautions

it  
(l@"

pages 2-4).

- Retain this manual for future reference.

(TO/O)

©

2010 TOSHIBA CORPORATION

**TOSHIBA**  
Leading Innovation >>>

# Owner's Manual

## 3D Glasses (FPT-AG01U)



**Content**

Safety Precautions.....

Accessories .....

Each part's name and function .....

Precautions for daily use .....

Enjoying 3D images .....

Replacing the battery .....

Care and Storage.....

Troubleshooting.....

Specifications .....

[Next Page](#)

1  
2  
3  
4  
5

# Related Manuals for Toshiba FPT-AG01

## [3D Glasses Toshiba FPT-AG01U Owner's Manual](#)

3d glasses (12 pages)

## [3D Glasses Toshiba FPT-AG02G User Manual](#)

Toshiba 3d glasses (108 pages)

## [3D Glasses TOSHIBA FPT-AG01G Owner's Manual](#)

3d glasses (8 pages)

## [3D Glasses Toshiba Passive 3D Glasses Description](#)

Passive 3d glasses (2 pages)

## Summary of Contents for Toshiba FPT-AG01

### [Page 1: Table Of Contents](#)

Replacing the battery Care and Storage Troubleshooting Specifications Thank you for purchasing a Toshiba product. • Please read this manual carefully, and use this product safely and correctly. Before use, be sure to read Safety Precautions pages 2-4). (l@" • Retain this manual for future reference.

### [Page 2: Safety Precautions](#)

Caution About handling the 3D Glasses • Do not use the 3D Glasses if they are not working properly or broken. Continuing to use them in such a state may cause injury, eye strain, or indisposition. Do not use the 3D Glasses if they are broken or have any cracks.

[Page 3](#) • When watching 3D images, do not wear 3D Glasses while tilted and do not lie down. If you watch while lying down or tilted, the 3D effect is lost and it may cause eye strain. • It is recommended that the viewer's eyes and 3D Glasses are level with...

[Page 4](#) • If you have prescription eye glasses or contact lenses, wear the 3D glasses over them. Watching 3D images without appropriate eyewear may cause eye strain. • If 3D images often appear in double or if you cannot see the images in 3D, stop viewing. Continuous viewing may cause eye strain.

[Page 5](#) FCC STARTMENT This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

### [Page 6: Accessories](#)

[1]= the quantity. Each part:s name and function Lens (liquid-crystal Power button and power light Power Turns on or off the power of 3D shutter) button A right and left liquid- Glasses by keeping pressing the power button for about 1 second.

### [Page 7: Precautions For Daily Use](#)

• Do not drop or bend the 3D Glasses. Notes on 1ft communication • Do not block the IR sensor for 3D Glasses on the TV by placing objects in front of it. • Do not cover the IR sensor on the 3D Glasses with stickers or labels.

### [Page 8: Enjoying 3D Images](#)

Setting television so that 3D images will be shown properly. • See the television owner's manual. Using the 3D Glasses. • When you use for the first time, pull out the insulation sheet inserted in the battery cover part. Pull out Hold down the 3D Glasses power button for about 1 second.

## [Page 9: Replacing The Battery](#)

- First remove any dirt or dust from the the 3D Glasses. - Harsh rubbing or use of a dirty or stiff cloth will scratch the 3D Glasses. • Do not use benzene, thinner, alcohol, water, or abrasive cleaners, which may damage the 3D Glasses.

## [Page 10: Troubleshooting](#)

3D Glasses is turned off. • Ensure you wear the appropriate glasses or contact lenses if necessary. 3D images are not • The left and right of the 3D images might be correct. reversed or the signal system of 3D images might be different.

## [Page 11: Specifications](#)

The battery operating time may become shorter depending on the usage condition or environment. • The included battery is for testing purpose only, and its life may be shorter than the above-mentioned time. • The specification may change without notice.

[Page 12](#) TOSHIBA AMERICA CONSUMER PRODUCTS, L.L.C. Corporate Headquarters: 82 TOTOWA ROAD, WAYNE, NJ 07470, U.S.A. NATIONAL SERVICE DIVISION: 1420-B TOSHIBA DRIVE, LEBANON, TN 37087, U.S.A. TOSHIBA OF CANADA LTD. HEAD OFFICE: 191 McNABB STREET, MARKHAM, ONTARIO, L3R 8H2, CANADA - TEL: (905) 470-5400...

[Page 13](#) CONDITIONS REPRESENTATIONS recertified pair without charge to you. You will be responsible for the cost to send the 3D OTHERWISE LIMITED IN DURATION TO THE TERM OF THIS EXPRESS WRITTEN glasses to TCL. Please keep the original carton box to help ensure the proper LIMITED WARRANTY.

[Page 14](#) (iv) the relationships that result from this warranty, (the foregoing claims, disputes or used in the context of the promotion or sale of, the 3D Glasses, on the other hand, controversies and disagreements are collectively referred to as the "Dispute"), shall be the provisions of this limited warranty shall prevail.

[Page 15](#) Un mauvais usage, un abus, de l'humidite, de liquides, de la poussiere, de la salete, Garantie limitee canadlenne de la negligence, d'un accident, d'un dommage, d'applications 24/7, d'exploitation inappropriee, d'un nettoyage inapproprie, d'un entretien inapproprie, de "usure Pour les lunettes 3D de marque Toshiba...

[Page 16](#) le service la clientele de TCL au numero sans vigueur sur le territoire ou vous residez en ce moment ou nait le litige. Si la loi ne frais 1-800-268-3404. l'interdit pas, aucune reclamation, ni differend, ni controverse ni desaccord de toute...

[Page 17](#) The warranty for Product rental units begins on the date of the first rental or thirty (30) (2) You must include the original bill of sale (or a copy of the original bill of sale) or other days after the date of shipment to the rental firm, whichever comes first.

[Page 18](#) TACP arising under the warranty or under any statute or law of the United States or any state thereof is hereby limited to ninety (90) days from the date you discover, or should have discovered, the defect.

This manual is also suitable for:

Fpt-ag01u