# System Memory - Asus PRIME H310M-A R1.0 Instruction Manual

```
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
```

```
18
19
20
21
22
23
24
25
26
27
28
29
```

•







# System memory Overview This motherboard comes with two Double Data Rate 4 (DDR4) Dual Inline Memory Module (DIMM) sockets. The figure illustrates the location of the DDR4 DIMM sockets: Recommended memory configuration

1-8 DIMM\_B1\* DIMM\_A1\*

You may install varying memory sizes in Channel A and Channel B. The system maps the total size of the lower-sized channel for the dual-channel configuration. Any excess memory from the higher-sized channel is then mapped for single-channel operation.

Always install DIMMs with the same CAS latency. For optimal compatibility, we recommend that you install memory modules of the same version or date code (D/C) from the same vendor. Check with the retailer to get the correct memory modules.

DDR4 2666MHz and higher memory modules will run at max. 2666MHz on Intel® 8th Generation 6-core or higher processors: DDR4 2400MHz and higher memory modules will run at max. 240 memory modules are series and series are series.

Memory modules with memory frequency higher than 2133 MHz and its

corresponding timing or the loaded X.M.P. Profile is not the JEDEC memory standard.

The stability and compatibility of these memory modules depend on the CPU's capabilities and other installed devices.

The default memory operation frequency is dependent on its Serial Presence Detect (SPD), which is the standard way of accessing information from a memory module. Under the default state, some memory modules for overclocking may operate at a lower frequency than the vendor-marked value.

For system stability, use a more efficient memory cooling system to support a full memory load (2 DIMMs).

Refer to www.asus.com for the latest Memory QVL (Qualified Vendors List)

Channel A

Channel B

\*

Chapter 1: Product introduction

DIMM\_A1\* DIMM\_B1\*

**Table of Contents** 

Previous Page Next Page

... 

### Related Manuals for Asus PRIME H310M-A R1.0

Motherboard Asus PRIME H310M-A User Manual

(29 pages)

Motherboard Asus PRIME H310M-A R2.0 Manual

(29 pages)

Motherboard Asus PRIME H310M-AT R2.0 Manual

(29 pages)

Motherboard Asus PRIME H310M-AT R2.0 Quick Start Manual

(2 pages)

Motherboard Asus PRIME H310M-AT Quick Start Manual

(2 pages)

Motherboard Asus Prime H310M-C Manual

(28 pages)

Motherboard Asus PRIME H310M-K Manual

(27 pages)

Motherboard Asus PRIME H310M-R R2.0 Manual

(25 pages)

Motherboard Asus TUF H310M-PLUS GAMING R2.0 Manual

(27 pages)

Motherboard Asus PRIME H310M-D R2.0 Manual

(27 pages)

Motherboard Asus PRIME H310M-D Manual

(29 pages)

Motherboard Asus PRIME H310M-E R2.0 Manual

(28 pages)

Motherboard Asus PRIME H310M-CS R2.0 Manual

(25 pages)

Motherboard Asus PRIME H310M2 R2.0 Manual

(26 pages)

Motherboard Asus H310M-IM-A Manual

(66 pages)

Motherboard Asus PRIME H310M-C/PS R2.0 Manual

(54 pages)

## Related Content for Asus PRIME H310M-A R1.0

**ROG RAMPAGE V EDITION 10 System Memory** 

Asus ROG RAMPAGE V EDITION 10

Q170A-IM-A System Memory

Asus Q170A-IM-A

**Z13PE-D16 System Memory** 

Asus Z13PE-D16
WS X299 SAGE System Memory
Asus WS X299 SAGE
Pro A620M-C-CSM System Memory
Asus Pro A620M-C-CSM
TUF GAMING B650-E WIFI System Memory
Asus TUF GAMING B650-E WIFI
H110M-P/DVI System Memory
Asus H110M-P/DVI
PCI/I-P54SP4 Upgrading System Memory
Asus PCI/I-P54SP4

# This manual is also suitable for:

Prime h310m-a