

Audio; Dolby Digital / Dts / Mpeg; Sample Freq. (Frequency); Drc (Dynamic Range Control) - Toshiba SD-V383SC Owner's Manual

Dvd video player & video cassette recorder

1

2

3

Table Of Contents

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42

--

•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



Initial Settings - DVD (Continued)

AUDIO

Each DVD disc has a variety of audio output options. Set this unit's AUDIO options according to the type of audio system you use.

Dolby Digital / DTS / MPEG

Bitstream: Select "Bitstream" if you connect the DVD+VCR's DIGITAL AUDIO OUT jack to an amplifier or other equipment with a Dolby Digital, DTS or MPEG decoder.

PCM (for Dolby Digital / MPEG): Select when connected to a two-channel digital stereo amplifier. DVDs encoded in Dolby Digital or MPEG will be



automatically downmixed to two-channel PCM audio.


Off (for DTS): If you select "Off", the DTS signal is not output through the DIGITAL AUDIO OUT jack.

Sample Freq. (Frequency)

If your receiver or amplifier is NOT capable of handling 96 kHz signals, select 48 kHz. When this choice is made, this unit automatically converts any 96 kHz signals to 48 kHz so your system can decode them.

If your receiver or amplifier is capable of handling 96 kHz signals, select 96 kHz. When this choice is made, this unit passes each type of signal through without any further processing.

Check the documentation for your amplifier's capabilities.



DRC (Dynamic Range Control)

With the DVD format, you can hear a program's sound track in the most accurate and realistic presentation possible, thanks to digital audio technology. However, you may wish to compress the dynamic range of the audio output (the difference between the loudest sounds and the quietest ones). This allows you to listen to a movie at a lower volume without losing clarity of sound. Set DRC to On for this effect.



OTHERS

The PBC, Auto Play, and B.L.E. settings can be changed.

PBC

Set Playback Control (PBC) to On or Off.

On: Video CDs with PBC are played according to the PBC.

Off: Video CDs with PBC are played the same way as Audio CDs.

Auto Play

You can set up the DVD+VCR so a DVD disc automatically starts playing whenever the DVD is inserted. If Auto Play mode is set to On, this DVD player will search for title that has the longest playback time and

then play back the title automatically.

On: Auto Play function is active.

Off: Auto Play function is not active.

Note:

The Auto Play function may not work for some DVDs.

B.L.E. (Black Level Expansion)

To select the black level of playback pictures. Set your preference and monitor's ability.

On: Expanded grey scale. (0 IRE cut off)

Off: Standard grey scale. (7.5 IRE cut off)



[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
...
16
17
18
19
20
21
22
23

Quick Links:

[Remote Control](#)

[Basic Tv Connections](#)

[Copying from DVD to Vcr](#)

Related Products for Toshiba SD-V383SC

[Toshiba SD-V395](#)

[Toshiba SD-V392 - DVD/VCR Combo](#)

[Toshiba SD-V390](#)

[Toshiba SD-V393](#)

[Toshiba SD-V396](#)

[Toshiba SD-V393SU2](#)

[Toshiba SDV398](#)

[Toshiba SD-V395KC](#)

[Toshiba SD-V392SU](#)

[Toshiba SD V394 - DVD/VCR Combo](#)

[Toshiba SD-V330SC2](#)

[Toshiba SD-V330SC](#)

[Toshiba SDV391c](#)

[Toshiba SDV391U](#)

[Toshiba SD-V394SC](#)

[Toshiba SD-V340SC](#)