





Asus E17919 Manual



1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14


15

16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102



•

[Table of Contents](#)

•

## Bookmarks



[Download this manual](#)

## Quick Links



E17919

First Edition / August 2021

E-Manual

**HDMI**<sup>™</sup>  
HIGH-DEFINITION MULTIMEDIA INTERFACE



## Table of Contents

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Asus E17919

### [Laptop Asus E1701b Hardware User Manual](#)

Asus notebook pc hardware user's manual (76 pages)

### [Laptop Asus E1796 Hardware User Manual](#)

Asustek user's manual notebook pc e1796 (74 pages)

### [Laptop Asus E17888 E-Manual](#)

(116 pages)

### [Laptop Asus E17820 E-Manual](#)

(94 pages)

### [Laptop Asus E17889 User Manual](#)

(16 pages)

### [Laptop Asus E17305 Manual](#)

(100 pages)

### [Laptop Asus E1916 Hardware User Manual](#)

Asustek computer notebook pc user's manual (72 pages)

### [Laptop Asus E1887 Hardware User Manual](#)

Notebook pc (76 pages)

### [Laptop Asus E12461 E-Manual](#)

(98 pages)

### [Laptop Asus VivoBook E12 E-Manual](#)

(94 pages)

### [Laptop Asus E15729 E-Manual](#)

(94 pages)

### [Laptop Asus E10584 E-Manual](#)

Notebook pc (118 pages)

### [Laptop Asus E10750 E-Manual](#)

Notebook pc (128 pages)

### [Laptop Asus E15025 Manual](#)

(86 pages)

### [Laptop Asus E16099 E-Manual](#)

(92 pages)

### [Laptop Asus Eee PC 1015 Series User Manual](#)

(58 pages)

## Summary of Contents for Asus E17919

[Page 1](#) E17919 First Edition / August 2021 E-Manual...

[Page 2](#) Warranty Statement, up to the listed contract price of each product. ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

### [Page 3: Table Of Contents](#)

Table of Contents About this manual .....7 Conventions used in this manual  
.....8 Icons ..... 8 Typography .....8 Safety precautions  
.....9 Using your Notebook PC .....9 Caring for your Notebook PC

.....10 Proper disposal ..... 11 Battery safety information.....

[Page 4](#) Chapter 3: Working with Windows® 10 Starting for the first time .....48 Start menu .....49 Windows® apps .....51 Working with Windows® apps.....52 Customizing Windows® apps .....52 Task view .....55 Snap feature .....56 Snap hotspots .....56 Action Center .....58 MyASUS Splendid .....59 Other keyboard shortcuts .....61 Connecting to wireless networks .....63...

[Page 5](#) Tips and FAQs Useful tips for your Notebook PC .....76 Hardware FAQs .....78 Software FAQs .....81 Appendices DVD-ROM Drive Information .....84 Blu-ray ROM Drive Information ..... 86 Internal Modem Compliancy .....86 Overview .....87 Network Compatibility Declaration ..... 87 Non-Voice Equipment .....

[Page 6](#) EU RoHS.....98 Japan JIS-C-0950 Material Declarations .....98 India RoHS ..... 98 Vietnam RoHS .....99 ASUS Recycling/Takeback Services .....99 Rechargeable Battery Recycling Service in North America.....99 Ecodesign Directive ..... 99 ENERGY STAR Qualified Product .....100 EPEAT Registered Products .....

## [Page 7: About This Manual](#)

About this manual This manual provides information about the hardware and software features of your Notebook PC, organized through the following chapters: Chapter 1: Hardware Setup This chapter details the hardware components of your Notebook Chapter 2: Using your Notebook PC This chapter shows you how to use the different parts of your Notebook PC.

## [Page 8: Conventions Used In This Manual](#)

Conventions used in this manual To highlight key information in this manual, some text are presented as follows: **IMPORTANT!** This message contains vital information that must be followed to complete a task. **NOTE:** This message contains additional information and tips that can help complete tasks.

## [Page 9: Safety Precautions](#)

Safety precautions Using your Notebook PC This Notebook PC should only be used in environments with ambient temperatures between 5°C (41°F) and 35°C (95°F). Refer to the rating label on the bottom of your Notebook PC and ensure that your power adapter complies with this rating.

## [Page 10: Caring For Your Notebook Pc](#)

Caring for your Notebook PC Disconnect the AC power and remove the battery pack (if applicable) before cleaning your Notebook PC. Use a clean cellulose sponge or chamois cloth dampened with a solution of nonabrasive detergent and a few drops of warm water. Remove any extra moisture from your Notebook PC using a dry cloth.

## [Page 11: Proper Disposal](#)

Do not use your Notebook PC near gas leaks. Do not place active electronic devices close to your Notebook PC to avoid electromagnetic wave interference to the display panel. Do not use this Notebook PC for cryptocurrency mining (consuming a vast amount of electricity and time to gain convertible virtual currency) and/or related activities.

## [Page 12: Battery Safety Information](#)

Battery safety information Battery protection • Frequently charging a battery under high voltage may shorten the battery life. To protect the battery, once the battery is fully charged, the system may stop charging when the battery power is between 90% and 100%. **NOTE:** The initiate battery power charging capacity is usually set between 90% and 99%.

[Page 13](#) Standard battery care • If you are not using your device for a long period of time, ensure to charge the battery power to 50% then power off your device and disconnect the AC power adapter. Recharge the battery power to 50% every three months to avoid over-discharging and prevent damage to the battery.

[Page 14](#) Notebook PC E-Manual...

## [Page 15: Chapter 1: Hardware Setup](#)

Chapter 1: Hardware Setup Notebook PC E-Manual...

## [Page 16: Getting To Know Your Notebook Pc](#)

Getting to know your Notebook PC Top View NOTE: The keyboard's layout may vary per region or country. The Notebook view may also vary in appearance depending on the Notebook PC model. Notebook PC E-Manual...

[Page 17](#) Array microphones The array microphones feature echo canceling, noise suppression, and beam forming functions for better voice recognition and audio recording. Webcam shield This allows you to cover the camera lens of your Notebook PC. Camera The built-in camera allows you to take pictures or record videos using your Notebook PC.

[Page 18](#) Microphone indicator This indicator lights up when the microphone is turned off. Keyboard The keyboard provides full-sized QWERTY keys with a comfortable travel depth for typing. It also enables you to use the function keys, allows quick access to Windows®, and controls other multimedia functions.

[Page 19](#) Touchpad The touchpad allows the use of multi-gestures to navigate onscreen, providing an intuitive user experience. It also simulates the functions of a regular mouse. NOTE: For more details, refer to the Using the touchpad section in this manual. DialPad Use DialPad to adjust volume, change brush opacity, increase or decrease display brightness, and much more.

[Page 20](#) Camera off indicator This indicator lights up when the camera is turned off. Power button Press the power button to turn your Notebook PC on or off. You can also use the power button to put your Notebook PC to sleep or hibernate mode and wake it up from sleep or hibernate mode.

## [Page 21: Bottom View](#)

Notebook PC. The battery pack cannot be disassembled. • Purchase components from authorized retailers to ensure maximum compatibility and reliability. Consult an ASUS service center or authorized retailers for product service or assistance on proper disassembly or assembly of the product.

[Page 22](#) Air vents The air vents allow cool air to enter and warm air to exit the Notebook PC. WARNING! Ensure that paper, books, clothing, cables, or other objects do not block any of the air vents or else overheating may occur.

## [Page 23: Right View](#)

Right View Intel model (N7600P/P7600CP) AMD model (M7600Q/Y7600CQ)

Headphone/Headset/Microphone jack This port allows you to connect amplified speakers or headphones. You can also use this port to connect your headset or an external microphone.

MicroSD card slot This built-in memory card reader slot supports microSD card formats.

[Page 24](#) • To prevent any damage, use only power sources rated 20V/5A to charge your Notebook PC with the USB Power Delivery combo port. For more information, consult an ASUS service center for assistance. HDMI output port This port allows you to connect your Notebook PC to another HDMI-compatible device for file sharing or extending your display monitor.

[Page 25](#) USB 3.2 Gen 1 port The USB 3.2 (Universal Serial Bus 3.2) Gen 1 port provides a transfer rate of up to 5 Gbit/s and is backward compatible to USB 2.0. Power (DC) input port Insert the bundled power adapter into this port to charge the battery pack and supply power to your Notebook PC.

## [Page 26: Left View](#)

Left View USB 2.0 port The USB (Universal Serial Bus) port is compatible with USB 2.0 or USB 1.1 devices such as keyboards, pointing devices, flash disk drives, external HDDs, speakers, cameras and printers. Status indicators The status indicators help identify the current hardware status of your Notebook PC.



[Page 27](#) Two-color battery charge indicator The two-color LED provides a visual indication of the battery's charge status. Refer to the following table for details: Color Status The Notebook PC is plugged to Solid White a power source and the battery power is between 95% and 100%.

[Page 28](#) Notebook PC E-Manual...

## [Page 29: Chapter 2: Using Your Notebook Pc](#)

Chapter 2: Using your Notebook PC Notebook PC E-Manual...

## [Page 30: Getting Started](#)

Getting started Charge your Notebook PC Connect the AC power cord to the AC/DC adapter. Connect the DC power connector into your Notebook PC's power (DC) input port. Plug the AC power adapter into a 100V~240V power source. Charge the Notebook PC for 3 hours before using it in battery mode for the first time.

[Page 31](#) WARNING! Read the following precautions for your Notebook PC's battery: • Only ASUS-authorized technicians should remove the battery inside the device (for non-removable battery only). • The battery used in this device may present a risk of fire or chemical burn if removed or disassembled.

## [Page 32: Lift To Open The Display Panel](#)

Lift to open the display panel Press the power button Notebook PC E-Manual...

## [Page 33: Using The Touchpad](#)

Using the touchpad Moving the pointer You can tap anywhere on the touchpad to activate its pointer, then slide your finger on the touchpad to move the pointer onscreen. Slide horizontally Slide vertically Slide diagonally Notebook PC E-Manual...

[Page 34](#) One-finger gestures Tap/Double-tap • Tap an app to select it. • Double-tap an app to launch it. Drag and drop Double-tap an item, then slide the same finger without lifting it off the touchpad. To drop the item to its new location, lift your finger from the touchpad.

[Page 35](#) Left-click Right-click • Click an app to select it. Click this button to open the right-click menu. • Double-click an app to launch it. NOTE: The areas inside the dotted line represent the locations of the left mouse button and the right mouse button on the touchpad. Two-finger gestures Tap two fingers on the touchpad to simulate the right-click function.

[Page 36](#) Two-finger scroll (up/down) Two-finger scroll (left/right) Slide two fingers to scroll up or Slide two fingers to scroll left or down. right. Zoom out Zoom in Bring together your two fingers on Spread apart your two fingers on the touchpad. the touchpad.

[Page 37](#) Drag and drop Select an item then press and hold the left button. Using your other finger, slide on the touchpad to drag the item, lift your finger off the button to drop the item. Three-finger gestures Tap three fingers on the touchpad to invoke Cortana. Notebook PC E-Manual...

[Page 38](#) Swipe left/Swipe right If you opened multiple apps, swipe three fingers left or right to switch between these apps. Swipe up Swipe down Swipe up to see an overview of all Swipe down to show the desktop. the apps currently opened. Notebook PC E-Manual...

[Page 39](#) Four-finger gestures Tap four fingers on the touchpad to invoke Action Center. Customizing your touchpad Launch All settings from the Action Center. Select Devices, then select Touchpad. Adjust the settings to your preference. Notebook PC E-Manual...

## [Page 40: Using The Dialpad](#)

Using the DialPad Launching the DialPad Press and hold then slide your finger in the direction as shown to launch the DialPad. Notebook PC E-Manual...

[Page 41](#) Launching the DialPad UI Tap/Click the dial on the DialPad to launch the DialPad UI onscreen. Tap/Click the dial again to navigate through the menus. Notebook PC E-Manual...

[Page 42](#) Using the dial • Rotate the dial on the DialPad to select a function. • Rotate the dial on the DialPad to adjust the selected function. Working with the DialPad UI Move the cursor to the DialPad UI onscreen then tap and hold the dotted area to move the DialPad UI to a new location.

[Page 43](#) Working with ProArt Creator Hub • Move the cursor to the DialPad UI onscreen then tap and hold anywhere on the DialPad to show the pop-up icons. Tap to launch the Control Settings page of ProArt Creator Hub. • From the Control Settings page, select Add Group or Add Function to customize the DialPad functions.

### [Page 44: Using The Keyboard](#)

Using the keyboard HotKeys The HotKeys on your Notebook PC's keyboard can trigger the following commands: Turns the speaker on or off Turns the speaker volume down Turns the speaker volume up Decreases display brightness Increases display brightness Enables or disables the touchpad Adjusts brightness for the backlit keyboard Toggles the display mode  
NOTE: Ensure that the second display is connected to...

### [Page 45: Function Keys](#)

Turns the microphone on or off Turns the camera on or off Activates screen capture tool Launches MyASUS Function keys Press to enable or disable the function keys feature. When the function keys feature is enabled, you can also access HotKeys by holding down in combination with the top row keys.

### [Page 46: Using The Numeric Keypad](#)

Using the numeric keypad NOTE: The numeric keypad layout may differ by model or territory but the usage procedures remain the same. A numeric keypad is available on selected Notebook PC models. You can use this keypad for numeric input or as pointer direction keys.

### [Page 47: Chapter 3: Working With Windows](#)

Chapter 3: Working with Windows® 10 Notebook PC E-Manual...

### [Page 48: Starting For The First Time](#)

Starting for the first time When you start your Notebook PC for the first time, a series of screens appear to guide you in configuring your Windows® 10 operating system. To start your Notebook PC for the first time: Press the power button on your Notebook PC. Wait for a few minutes until the setup screen appears.

### [Page 49: Start Menu](#)

Start menu The Start menu is the main gateway to your Notebook PC's programs, Windows® apps, folders, and settings. Change account settings, lock, or sign out from your account Launch an app from the Start screen Launch an app from the taskbar Launch Taskview Launch Search Launch the Start menu...

[Page 50](#) Launching the Start menu Position your mouse pointer over the Start button in the lower-left corner of your desktop then click it. Press the Windows logo key on your keyboard. Opening programs from the Start menu One of the most common uses of the Start menu is opening programs installed on your Notebook PC.

### [Page 51: Windows® Apps](#)

Windows ® apps These are apps pinned on the right pane of the Start menu and displayed in tiled-format for easy access. NOTE: Some Windows® apps require signing in to your Microsoft account before they are fully launched. Notebook PC E-Manual...

### [Page 52: Working With Windows® Apps](#)

Working with Windows® apps Use your Notebook PC's touchpad or keyboard to launch, customize, and close apps. Launching Windows® apps from the Start menu Position your mouse pointer over the app then click to launch it. Use the arrow keys to browse through the apps. Press to launch an app.

[Page 53](#) Resizing apps Position your mouse pointer over the app and right-click it, then click Resize and select an app tile size. Use the arrow keys to navigate to the app. Press (on selected

models), then select **Resize** and select an app tile size. Unpinning apps Position your mouse pointer over the app and right-click it, then click **Unpin from Start**.

[Page 54](#) **Pinning apps to the taskbar** Position your mouse pointer over the app and right-click it, then click **Pin to taskbar**. Use the arrow keys to navigate to the app. Press (on selected models), then select **Pin to taskbar**. **Pinning more apps to the Start menu** From **All apps**, position your mouse pointer over the app you want to add to the Start menu and right-click it, then click **Pin to Start**.

### [Page 55: Task View](#)

**Task view** Quickly switch between opened apps and programs using the task view feature, you can also use task view to switch between desktops. **Launching task view** Position your mouse pointer over the icon on the taskbar and click it. Press on your keyboard.

### [Page 56: Snap Feature](#)

**Snap feature** The Snap feature displays apps side-by-side, allowing you to work or switch between apps. **Snap hotspots** You can drag and drop apps to these hotspots to snap them into place. Notebook PC E-Manual...

[Page 57](#) **Using Snap** Launch the app you wish to snap. Drag the title bar of your app and drop the app to the edge of the screen to snap. Launch another app and repeat the above steps to snap another app. Launch the app you wish to snap.

### [Page 58: Action Center](#)

**Action Center** Action Center consolidates notifications from apps and presents a single place where you can interact with them. It also has a really useful **Quick Actions** section at the bottom. **Launching Action Center** Position your mouse pointer over the icon on the taskbar and click it.

### [Page 59: MyASUS Splendid](#)

**MyASUS Splendid** MyASUS Splendid ensures that all ASUS display panels show identical and accurate colors. You may select **Vivid**, **Eye Care**, or **Manual Mode** beside **Normal Mode** to adjust the display settings. **Normal Mode**: Through Gamma and Color temperature •...

[Page 60](#) Please refer to the following tips to alleviate eye strain: • Take some time away from the display if working for long hours. It is advised to take short breaks (at least 5 minutes) after around 1 hour of continuous working at the computer. Taking short and frequent breaks is more effective than a long break.

### [Page 61: Other Keyboard Shortcuts](#)

**Other keyboard shortcuts** Using the keyboard, you can also use the following shortcuts to help you launch applications and navigate **Windows® 10**. Launches **Start menu** Launches **Action Center** Launches the desktop Launches the **File Explorer** Launches **Settings** Launches **Connect panel** Activates the **Lock screen** Minimizes all currently active windows Notebook PC E-Manual...

[Page 62](#) Launches **Search** Launches **Project panel** Opens the **Run window** Opens **Ease of Access Center** Opens the context menu of the **Start button** Launches the **magnifier icon** and zooms in your screen Zooms out your screen Notebook PC E-Manual...

### [Page 63: Connecting To Wireless Networks](#)

**Connecting to wireless networks** **Wi-Fi** Access emails, surf the Internet, and share applications via social networking sites using your Notebook PC's Wi-Fi connection. **IMPORTANT!** **Airplane mode** disables this feature. Ensure that **Airplane mode** is turned off before enabling the Wi-Fi connection of your Notebook PC.

### [Page 64: Bluetooth](#)

**Bluetooth** Use Bluetooth to facilitate wireless data transfers with other Bluetooth-enabled devices. **IMPORTANT!** **Airplane mode** disables this feature. Ensure that **Airplane mode** is turned off before enabling the Bluetooth connection of your Notebook PC. **Pairing with other Bluetooth-enabled devices** You need to pair your Notebook PC with other Bluetooth-enabled devices to enable data transfers.

## [Page 65: Airplane Mode](#)

Airplane mode Airplane mode disables wireless communication, allowing you to use your Notebook PC safely while in-flight. NOTE: Contact your airline provider to learn about related in-flight services that can be used and restrictions that must be followed when using your Notebook PC in-flight. Turning Airplane mode on Launch Action Center from the taskbar.

## [Page 66: Turning Your Notebook Pc Off](#)

Turning your Notebook PC off You can turn off your Notebook PC by doing either of the following procedures:

- Launch the Start menu, then select > Shut down to do a normal shutdown.
- From the log-in screen, select >...

## [Page 67: Putting Your Notebook Pc To Sleep](#)

Putting your Notebook PC to sleep To put your Notebook PC to Sleep mode:

- Launch the Start menu, then select > Sleep to put your Notebook PC to sleep.
- From the log-in screen, select > Sleep. Press to launch Shut down Windows.

## [Page 68](#) Notebook PC E-Manual...

## [Page 69: Chapter 4: Power-On Self-Test \(Post\)](#)

Chapter 4: Power-On Self-Test (POST) Notebook PC E-Manual...

## [Page 70: The Power-On Self-Test \(Post\)](#)

The Power-On Self-Test (POST) The POST (Power-On Self-Test) is a series of software-controlled diagnostic tests that run when you turn on or restart your Notebook PC. The software that controls the POST is installed as a permanent part of the Notebook PC's architecture. Using POST to access BIOS and Troubleshoot During POST, you can access the BIOS settings or run troubleshooting options using the function keys of your Notebook PC.

## [Page 71: Accessing Bios](#)

Accessing BIOS Enter the BIOS settings by using any of the following methods:

- Restart your Notebook PC then press during POST.
- Launch the Start menu, and choose Settings > Update & security > Recovery, then select Restart now under Advanced startup.

## [Page 72: Recovering Your System](#)

Recovering your system Using recovery options on your Notebook PC allows you to restore the system to its original state or simply refresh its settings to help improve performance. IMPORTANT! Backup all your data files before doing any recovery option on your •...

## [Page 73: Performing A Recovery Option](#)

Go back to an earlier build - This option allows you to go back • to an earlier build. Use this option if this build is not working for you. Advanced startup - Using this option allows you to perform •...

[Page 74](#) Under the Update and security option, select Recovery then select the recovery option you would like to perform. Notebook PC E-Manual...

## [Page 75: Tips And Faqs](#)

Tips and FAQs Notebook PC E-Manual...

## [Page 76: Useful Tips For Your Notebook Pc](#)

Update Windows® periodically to ensure that your applications have the latest security settings.

- Update MyASUS to ensure that you have the latest settings for ASUS exclusive applications, drivers, and utilities.
- Use an anti-virus software to protect your data and keep this updated too.

[Page 77](#) Product key for your operating systems and other installed applications Backup data Log in ID and password Internet connection information • Visit our support site for troubleshooting and view some of the most frequently asked questions at

### [Page 78: Hardware Faqs](#)

I turn on the Notebook PC. What should I do? Although these dots normally appear onscreen, they will not affect your system. If the incident continues and subsequently affects system performance, consult an authorized ASUS service center. My display panel has an uneven color and brightness. How...

[Page 79](#) Notebook PC. • If the problem still exists, contact your local ASUS service center for assistance. Why is my touchpad not working? Press to enable your touchpad.

[Page 80](#) What should I do if my Notebook PC's power adapter gets lost or my battery stops working? Contact your local ASUS service center for assistance. My Notebook PC cannot do keystrokes correctly because my cursor keeps on moving. What should I do? Make sure that nothing accidentally touches or presses on your touchpad while you type on the keyboard.

### [Page 81: Software Faqs](#)

Notebook PC. • If the problem still exists, contact your local ASUS service center for assistance. What should I do when my screen displays this message: "Remove disks or other media. Press any key to restart."? You can try doing any of the following suggestions: •...

[Page 82](#) • Remove all connected devices to your Notebook PC then restart your system. • If the problem still exists, contact your local ASUS service center for assistance. Why can't my Notebook PC wake up from sleep mode? • You need to press the power button to resume your last working state.

### [Page 83: Appendices](#)

Appendices Notebook PC E-Manual...

### [Page 84: Dvd-Rom Drive Information](#)

DVD-ROM Drive Information The DVD-ROM drive allows you to view and create your own CDs and DVDs. You can purchase an optional DVD viewer software to view DVD titles. NOTE: The DVD-ROM Drive is available on selected models. Regional Playback Information Playback of DVD movie titles involves decoding MPEG2 video, digital AC3 audio and decryption of CSS protected content.

[Page 85](#) Region Definitions Region 1 Canada, US, US Territories Region 2 Czech, Egypt, Finland, France, Germany, Gulf States, Hungary, Iceland, Iran, Iraq, Ireland, Italy, Japan, Netherlands, Norway, Poland, Portugal, Saudi Arabia, Scotland, South Africa, Spain, Sweden, Switzerland, Syria, Turkey, UK, Greece, Former Yugoslav Republics, Slovakia Region 3 Burma, Indonesia, South Korea, Malaysia, Philippines, Singapore, Taiwan, Thailand,...

### [Page 86: Blu-Ray Rom Drive Information](#)

Blu-ray ROM Drive Information The Blu-ray ROM Drive allows you to view HD (High-Definition) videos and other disc file formats such as DVDs and CDs. NOTE: The Blu-ray ROM Drive is available on selected models. Region Definitions Region A North, Central and South American countries, and their territories; Taiwan, Hong Kong, Macao, Japan, Korea (South and North), South East Asian countries and their territories.

### [Page 87: Overview](#)

Overview On 4th August 1998 the European Council Decision regarding the CTR 21 has been published in the Official Journal of the EC. The CTR 21 applies to all non voice terminal equipment with DTMF-dialling which is intended to be connected to the analogue PSTN (Public Switched Telephone Network).

[Page 88](#) This table shows the countries currently under the CTR21 standard. Country Applied More Testing Austria Belgium Czech Republic Not Applicable Denmark Finland France Germany Greece Hungary Not Applicable Iceland Ireland Italy Still Pending Still Pending Israel Lichtenstein Luxemburg The Netherlands Norway Poland Not Applicable...

[Page 89](#) This information was copied from CETECOM and is supplied without liability. For updates to this table, you may visit [http://www.cetecom.de/technologies/ctr\\_21.html](http://www.cetecom.de/technologies/ctr_21.html). 1 National

requirements will apply only if the equipment may use pulse dialling (manufacturers may state in the user guide that the equipment is only intended to support DTMF signalling, which would make any additional testing superfluous).

### [Page 90: Federal Communications Commission Interference Statement](#)

Federal Communications Commission Interference Statement This device complies with FCC Rules Part 15. Operation is subject to the following two conditions: • This device may not cause harmful interference. • This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the Federal Communications Commission (FCC) rules.

### [Page 91: Fcc Radio Frequency \(Rf\) Exposure Caution Statement](#)

FCC Radio Frequency (RF) Exposure Caution Statement WARNING! Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

### [Page 92: Compliance Statement Of Innovation, Science And Economic Development Canada \(Ised\)](#)

Compliance Statement of Innovation, Science and Economic Development Canada (ISED) This device complies with Innovation, Science and Economic Development Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### [Page 93: Ul Safety Notices](#)

UL Safety Notices Required for UL 1459 covering telecommunications (telephone) equipment intended to be electrically connected to a telecommunication network that has an operating voltage to ground that does not exceed 200V peak, 300V peak-to-peak, and 105V rms, and installed or used in accordance with the National Electrical Code (NFPA 70).

### [Page 94: Power Safety Requirement](#)

Power Safety Requirement Products with electrical current ratings up to 6A and weighing more than 3Kg must use approved power cords greater than or equal to: H05VV-F, 3G, 0.75mm H05VV-F, 2G, 0.75mm TV Notices Note to CATV System Installer—Cable distribution system should be grounded (earthed) in accordance with ANSI/NFPA 70, the National Electrical Code (NEC), in particular Section 820.93, Grounding of Outer Conductive Shield of a Coaxial Cable -...

### [Page 95: Nordic Lithium Cautions \(For Lithium-Ion Batteries\)](#)

Nordic Lithium Cautions (for lithium-ion batteries) CAUTION! Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. (English) ATTENZIONE! Rischio di esplosione della batteria se sostituita in modo errato. Sostituire la batteria con un una di tipo uguale o equivalente consigliata dalla fabbrica.

### [Page 96: Ctr 21 Approval \(For Notebook Pc With Built-In Modem\)](#)

CTR 21 Approval (for Notebook PC with built-in Modem) Danish Dutch English Finnish French Notebook PC E-Manual...

### [Page 97](#) German Greek Italian Portuguese Spanish Swedish Notebook PC E-Manual...

### [Page 98: Declaration Of Compliance For Product Environmental Regulation](#)

Environmental Regulation ASUS follows the green design concept to design and manufacture our products, and makes sure that each stage of the product life cycle of ASUS product is in line with global environmental regulations. In addition, ASUS disclose the relevant information based on regulation requirements.

### [Page 99: Vietnam Rohs](#)

ASUS products sold in Vietnam, on or after September 23, 2011, meet the requirements of the Vietnam Circular 30/2011/TT-BCT. Các sản phẩm ASUS bán tại Việt Nam, vào ngày 23 tháng 9 năm 2011 trở về sau, đều phải đáp ứng các yêu cầu của Thông tư 30/2011/TT-BCT của Việt Nam.

### [Page 100: Energy Star Qualified Product](#)

All ASUS products with the ENERGY STAR logo comply with the ENERGY STAR standard, and the power management feature is enabled by default. The monitor is automatically set to sleep within 10 minutes of user inactivity; the computer is automatically set to sleep within 30 minutes of user inactivity.

### [Page 101: Regional Notice For Singapore](#)

Regional notice for Singapore This ASUS product complies with IMDA Standards. Complies with IMDA Standards DB103778 Notices for removable batteries • Risk of explosion if battery is replaced by an incorrect type. • The battery and its component must be recycled or disposed of properly.

### [Page 102: Simplified Eu Declaration Of Conformity](#)

The Radio Equipment Regulations 2017 (S.I. 2017/1206). Full text of UKCA declaration of conformity is available at <https://www.asus.com/support/>. The WiFi operating in the band 5150-5350 MHz shall be restricted to indoor use...