

Asus LS246H User Manual

Ls246 series

```
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
```

18			
19			
20			

•

Table of Contents





Quick Links

- 1 Specifications Summary (Ls246H)
- 2 Troubleshooting.(Faq)

Download this manual



LS246 Series LCD-Montor

User Guide

Table of Contents

Next Page



Related Manuals for Asus LS246H

Monitor Asus LS221H User Manual

Asus Is221h: user guide (22 pages)

Monitor Asus LS248H User Manual

Ls248 series; (20 pages)

Monitor Asus LS201 Series User Manual

User guide (20 pages)

Monitor Asus LS201 Series Quick Start Manual

Lcd monitor (4 pages)

Monitor Asus LS201D User Manual

(20 pages)

Monitor Asus LED-22 User Manual

(21 pages)

Monitor Asus ROG SWIFT PG32UCDM User Manual

(43 pages)

Monitor Asus VG27AQ3A Series User Manual

Tuf gaming monitor (28 pages)

Monitor Asus PB238Q User Manual

Pb238g series lcd monitor (25 pages)

Monitor Asus VG248QG Series User Manual

(30 pages)

Monitor Asus VG248QE User Manual

24"w (16:9, 60.97 cm) wide screen (25 pages)

Monitor Asus VG34VQL3A Series User Manual

Tuf gaming monitor (33 pages)

Monitor Asus ROG SWIFT OLED PG32UCDP User Manual

(46 pages)

Monitor Asus MB19 Series User Manual

(30 pages)

Monitor Asus PA169CDV User Manual

(35 pages)

Monitor Asus VG249 Series User Manual

(28 pages)

Summary of Contents for Asus LS246H

Page 1 LS246 Series LCD Monitor User Guide...

Page 2: Table Of Contents

Adjusting.tne.monitor2-1 2.3. Connecting.tne.cables2-2 2.4.
Turning.on.the.monitor2-2 2.5. Turning.on.Light-In-Motion2-3
Chapter.3:General.instructions 3.1. OSD.(On-Screen.Display).menu3-1 3.1.1 How to
reconfigure3-1 3.1.2 OSD function introduction3-1 3.2 Specifications summary
(LS246H)3-4 3.3. Troubleshooting.(FAQ)3-5 3.4.
Supported.operating.modes3-6

Page 3: Notices

Notices Federal.Communications.Commission.Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: • This device may not cause harmful interference, and • This device must accept any interference received including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. The use of shielded cables for connection of the monitor to the graphics card is required to assure compliance with FCC regulations. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. As an Energy Star Partner, our company has determined that this product meets ® the Energy Star guidelines for energy efficiency. ®

Canadian.Department.of.Communications.Statement This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Page 4: Safety.information

Safety information • Before setting up the monitor, carefully read all the documentation that came with the package. • To prevent fire or shock hazard, never expose the monitor to rain or moisture. • Never try to open the monitor cabinet. The dangerous high voltages inside the monitor may result in serious physical injury. • If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer. • Before using the product, make sure all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately. • Slots and openings on the back or top of the cabinet are provided for ventilation. Do not block these slots. Never place this product near or over a radiator or heat source unless proper ventilation is provided. • The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supply to your home, consult your dealer or local power company. • Use the appropriate power plug which complies with your local power standard. • Do not overload power strips and extention cords. Overloading can result in fire or electric shock. • Avoid dust, humidity, and temperature extremes. Do not place the monitor in any area where it may become wet. Place the monitor on a stable surface. • Unplug the unit during a lightning storm or if it will not be used for a long period of time. This will protect the monitor from damage due to power surges. • Never push objects or spill liquid of any kind into the slots on the monitor cabinet. • To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100-240V AC.

Page 5: Care. &. Cleaning

Care & Cleaning • Before you lift or reposition your monitor, it is better to disconnect the cables and power cord. Follow the correct lifting techniques when positioning the monitor. When lifting or carrying the monitor, grasp the edges of the monitor. Do not lift the display by the stand or the cord. • Cleaning. Turn your monitor off and unplug the power cord. Clean the monitor surface with a lint-free, non-abrasive cloth. Stubborn stains may be removed with a cloth dampened with mild cleaner. • Avoid using a cleaner containing alcohol or acetone. Use a cleaner intended for use with the LCD. Never spray cleaner directly on the screen, as it may drip inside the monitor and cause an electric shock.

The.following.symptoms.are.normal.with.the.monitor: • The screen may flicker during the initial use due to the nature of the fluorescent light. Turn off the Power Switch and turn it on again to make sure that the flicker disappears. • You may find slightly uneven brightness on the screen depending on the desktop pattern you use. • When the same image is displayed for hours, an afterimage of the previous screen may remain after switching the image. The screen will recover slowly or you can turn off the Power Switch for hours. • When the screen becomes black or flashes, or cannot work anymore, contact your dealer or service center to fix it. Do not repair the screen by yourself! Conventions.used.in.this.guide WARNING: Information to prevent injury to yourself when trying to complete a task. CAUTION: Information to prevent damage to the components when trying to complete a task. IMPORTANT: Information that you MUST follow to complete a task. NOTE: Tips and additional information to aid in completing a task.

<u>Page 6</u> Where to find more information Refer to the following sources for additional information and for product and software updates. ASUS.websites The ASUS websites worldwide provide updated information on ASUS hardware and software products. Refer to http://www.asus.com Optional.documentation Your product package may include optional documentation that may have been added by your dealer. These documents are not part of the standard package.

Page 7: Welcome

Welcome! ® Thank you for purchasing the ASUS LS246 Series LCD monitor! The latest widescreen LCD monitor from ASUS provides a crisper, broader, and brighter display, plus a host of features that enhance your viewing experience. With these features, you can enjoy the convenience and delightful visual experience that the LS246 Series brings to you! Package contents Check your package for the following items: LCD monitor Quick start guide User guide CD Warranty card Power cord + power adapter VGA cable HDMI-DVI cable Cleaning cloth If any of the above items is damaged or missing, contact your retailer immediately.

Page 8: Monitor.introduction

Monitor introduction 1.3.1. Front.view button: • Selects a desired preset mode. • Exits the OSD menu or goes back to the previous menu when the OSD menu is active. • Automatically adjusts the image to its optimized position, clock, and phase by touching this button for 2-4 seconds (for VGA mode only). • Decreases values or moves your selection left/down. • Contrast hotkey MENU button: • Turns on the OSD menu. Enacts the selected OSD menu item. Chapter 1: Product introduction...

Page 9: Back View

Power button/power indicator • Turns the monitor on/off. • The color definition of the power indicator is as the below table. Status Description White Amber Standby mode button: • Selects an available input source. • Increases values or moves your selection right/up. • Brightness hotkey 1.3.2. Back.view DC-IN HDMI Rear.connectors DC-IN.port. This port connects the power cord. HDMI port. This port is for connection with an HDMI compatible device. VGA.port. This 15-pin port is for PC VGA connection. Earphone.jack. This port is only available when an HDMI cable is connected. This port is only available when an HDMI cable is connected. Kensington.lock.slot. ASUS LS246 Series LCD Monitor...

Page 10 Chapter 1: Product introduction...

Page 11: Assembling.the.monitor.base

Assembling the monitor base To assemble the monitor base: Have the front of the monitor face down on a table. Place the ring-shaped base on the back of the monitor by aligning the slots on the base with the pins on the monitor. Use a coin or the like to turn the screw until the ring-shaped base is securely attached to the monitor. We recommend that you cover the table surface with soft cloth to prevent damage to the monitor. Adjusting the monitor • F or optimal viewing, we recommend that you look at the full face of the monitor, then adjust the monitor to the angle that is most comfortable for you. • To adjust your viewing angle, gently push the top portion of the monitor or bring the monitor forwards as illustrated. • Y ou can adjust the monitor's angle from 10° to 25°. +10 to +25 It is normal that the monitor slightly shakes while you adjust the the viewing angle. ASUS LS246 Series LCD Monitor...

Page 12: Connecting.the.cables

Connecting the cables Connect the cables as the following instructions: DC-IN HDMI • To.connect.the.power.cord: Connect the power adapter securely to the monitor's DC input port. Connect one end of the power cord to the power adapter and the other end to a power outlet. • To connect the VGA/HDMI-DVI cable: Plug one end of the VGA/HDMI-DVI cable to the monitor's VGA/HDMI port. Connect the other end of the VGA/HDMI-DVI cable to your computer's VGA/DVI port. Tighten the two screws to secure the VGA/DVI connector. • To use the earphone (only when an HDMI cable, not the supplied HDMI- DVI cable, is connected): connect the end with plug type to the monitor's earphone jack. When these cables are connected, you can choose the desired signal from the Input Select item in the OSD menu. Turning on the monitor Tap the power button . See page 1-2 for the location of the power button. The power indicator lights up in white to show that the monitor is ON. Chapter 2: Setup...

Page 13: Turning.on.light-In-Motion

Turning on Light-In-Motion Tap MENU and turn the control wheel to select System. Setup. Tap MENU again and turn the control wheel to select Light-In-Motion. Tap MENU again and turn the

control wheel to select On. Tap repeatedly until the OSD menu disappears to save and exit the OSD. ASUS LS246 Series LCD Monitor...

Page 14 Chapter 2: Setup...

Page 15: Osd.(On-Screen.display).Menu

To exit and save the OSD menu, tap the button repeatedly until the OSD menu disappears. To adjust other functions, repeat steps 1-3. 3.1.2. OSD.function.introduction Splendid This function contains five sub-functions you can select for your preference. Each mode has the Reset selection, allowing you to maintain your setting or return to the preset mode. • Scenery.Mode: best choice for scenery photo display with SPLENDID™ Video Enhancement. • Standard.Mode: best choice for document editing with SPLENDID™ Video Enhancement. • Theater.Mode: best choice for movies with SPLENDID™ Video Enhancement. • Game.Mode: best choice for games playing with SPLENDID™ Video Enhancement. • Night.View.Mode: best choice for dark-scene games or movies with SPLENDID™ Video Enhancement. • In the Standard Mode, the Saturation and Sharpness functions are not user-configurable. • In the other modes, the sRGB function is not user-configurable. ASUS LS246 Series LCD Monitor...

Page 16 Image. You can adjust brightness, contrast, sharpness, saturation, position (VGA only), and focus (VGA only) from this menu. • Brightness: the adjusting range is from 0 to 100. To have a guick access to the adjustment menu, turn the control wheel clockwise. • Contrast: the adjusting range is from 0 to 100. To have a quick access to the adjustment menu, turn the control wheel counterclockwise. • ASCR: turns on/off the ASCR (ASUS Smart Control Ratio) function. • Sharpness: the adjusting range is from 0 to 100. • Saturation: the adjusting range is from 0 to 100. • Position: adjusts the horizontal position (H-Position) and the vertical position (V-Position) of the image. The adjusting range is from 0 to 100. • Focus: reduces Horizonal-line noise and Vertical-line noise of the image by adjusting (Phase) and (Clock) separately. The adjusting range is from 0 to 100. • Phase adjusts the phase of the pixel clock signal. With a wrong phase adjustment, the screen shows horizontal disturbances. • Clock (pixel frequency) controls the number of pixels scanned by one horizontal sweep. If the frequency is not correct, the screen shows vertical stripes and the image is not proportional. Color Select the image color you like from this function. • Color.Temp.: contains five color modes including Cool, Normal, Warm, sRGB, and User. • Skin.Tone: contains three color modes including Reddish, Natural, and Yellowish. In the User mode, colors of R (Red), G (Green), and B (Blue) are user- configurable; the adjusting range is from 0-100.

Page 17 Input.Select. In this function, you can select your desired input source. System. Setup. Allows you to adjust the system. • Light-In-Motion: Selecting "On" enables the lighting effect emitting around the control wheel. • Volume: the adjusting range is from 0 to 100. • Aspect.Control: adjusts the aspect ratio to full or 4:3. • OSD.Setup: Adjusts the horizontal position (H-Position)/the vertical position (V-Position) of the OSD from 0 to 100. Adjusts the OSD timeout from 10 to 120 seconds. Enables or disables the DDC/CI function. • Language: there are 11 languages for your selection, including English, German, Italian, French, Dutch, Spanish, Russian, Traditional Chinese, Simplified Chinese, Japanese and Korean. • Information: shows the monitor information. • All.Reset: "Yes" allows you to restore the default settings. ASUS LS246 Series LCD Monitor...

Page 18: Specifications Summary (Ls246H)

3.2 Specifications summary (LS246H) Panel.Type TFT LCD Panel.size 23.6" (16:9) wide screen Max..Resolution 1920 x 1080 Pixel.pitch 0.248 mm Brightness.(Max.) 250 cd/m Contrast.Ratio.(Typ.) 1200:1 Contrast.Ratio.(Max.) 50000:1 (with ASCR on) Viewing angle(H/V) CR>10 170°/160° Display.colors 16.7 M Response.time 2 ms SPLENDID™.Video. Enhancement SPLENDID™.selection 5 video preset modes (by hotkey) Auto.adjustment Yes (by hotkey) Color.temperature.selection 5 color temperatures Skin-Tone.selection 3 skin-tones Digital.input HDMI v1.3 Analog.input D-Sub Earphone.jack Yes (Only for HDMI) Colors Black Power.LED...

Page 19: Troubleshooting.(Faq)

Screen image bounces or a wave pattern is • Make sure the signal cable is properly present in the image connected to the monitor and the computer. • Move electrical devices that may cause electrical interference. Screen image has color defects (white does • Inspect the signal cable and make sure not look white) that none of the pins are bent. • Perform All Reset via OSD. • Adjust the R/G/B color settings or select the Color Temperature via OSD. Screen image is blurry or fuzzy • Touch the button for 2-4 seconds to automatically adjust the image (for VGA mode only). • Adjust the Phase and Clock settings via OSD. No sound or sound is low • Ensure that the HDMI cable is properly connected to the monitor and the computer. • Adjust the volume settings of both your monitor and HDMI device. • Ensure that the computer sound card

driver is properly installed and activated. ASUS LS246 Series LCD Monitor...

Page 20: Supported.operating.modes

Supported operating modes Resolution. Horizontal Vertical.Frequency. Pixel.. Frequency Frequency (KHz) (Hz) (MHz) 720 x 400 31.47 70.08 28.32 640 x 480 31.47 59.94 25.18 640 x 480 35.00 66.66 30.24 640 x 480 37.87 72.82 31.50 640 x 480 37.50 75.00 31.50 800 x 600 35.16 56.25 36.00 800 x 600 37.88 60.32 40.00 800 x 600 48.08 72.12 50.00...