

Platform Misc Configuration - Asus MAXIMUS VIII GENE User Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196

--

•

[Table of Contents](#)

•

Bookmarks



3.6.2

Platform Misc Configuration

The items in this menu allow you to configure the platform-related features.

PCI Express Native Power Management [Disabled]


Enable this item to enhance the PCI-E power saving condition.

Configuration options: [Disabled] [Enabled]

The following item appears only when you set the PCI Express Native Power Management to [Enabled].

Native ASPM [Disabled]

Enable this item for the Windows installation by setting it to On in the Active State Power Management (ASPM) support for devices.



[Disabled]

PCH - PCI Express

DMI Link ASPM Control [Disabled]

This item is for the control of the Active State Power Management on SA side of the DMI link.

Configuration options: [Enabled] [Disabled]

3-24

Vista controls the ASPM support for the device.

BIOS controls the ASPM support for the device.

Chapter 3: BIOS Setup

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
...
93
94
95
96
97
98
99
100

Quick Links:

[Motherboard Layout](#)

Related Manuals for Asus MAXIMUS VIII GENE

[Motherboard ASUS Maximus VII Ranger User Manual](#)

Motherboard (200 pages)

[Motherboard Asus MAXIMUS VI IMPACT User Manual](#)

Maximus vi impact user's manual (222 pages)

[Motherboard Asus Maximus VII Formula Series Manual](#)

(224 pages)

[Motherboard ASUS MAXIMUS VII IMPACT User Manual](#)

(238 pages)

[Motherboard ASUS MAXIMUS VII GENE User Manual](#)

(218 pages)

[Motherboard Asus Maximus VIII Ranger User Manual](#)

(200 pages)

[Motherboard ASUS Maximus VIII Hero User Manual](#)

(194 pages)

[Motherboard Asus MAXIMUS VIII EXTREME User Manual](#)

(226 pages)

[Motherboard Asus maximus viii formula User Manual](#)

(218 pages)

[Motherboard Asus MAXIMUS VII FORMULA Manual](#)

(7 pages)

[Motherboard Asus Maximus VII Hero Manual](#)

(200 pages)

[Motherboard Asus MAXIMUS VII HERO Manual](#)

(200 pages)

[Motherboard Asus MAXIMUS VI FORMULA User Manual](#)

Maximus vi formula user's manual (212 pages)

[Motherboard Asus MAXIMUS VI HERO Manual](#)

(182 pages)

[Motherboard ASUS Maximus VI Extreme User Manual](#)

(218 pages)

[Motherboard ASUS Maximus VI Extreme Manual](#)

(208 pages)

Related Content for Asus MAXIMUS VIII GENE

[H310M-IM-A Platform Misc Configuration](#)

Asus H310M-IM-A

[RAMPAGE V EDITION 10 Platform Misc Configuration](#)

Asus RAMPAGE V EDITION 10

[PRIME Z370-A II Series Platform Misc Configuration](#)

Asus PRIME Z370-A II Series

[STRIX Z270G GAMING Platform Misc Configuration](#)

Asus STRIX Z270G GAMING

[TUF X299 MARK 2 Platform Misc Configuration](#)

Asus TUF X299 MARK 2

[WS C422 SAGE/10G Platform Misc Configuration](#)

Asus WS C422 SAGE/10G

[90MB0U00-M0EAY0 Platform Misc Configuration](#)

Asus 90MB0U00-M0EAY0

[Pro WS X299 SAGE II Platform Misc Configuration](#)

Asus Pro WS X299 SAGE II